

1. Comparison of DDR3, DDR4 and DDR5 RAM

Feature	DDR3	DDR4	DDR5
Speed	800–2133 MT/s	1600–3200 MT/s	4800–8400+ MT/s
Voltage	1.5V	1.2V	1.1V
Performance	Basic	Better	Highest
Typical Use	Older PCs/ laptops	Modern PCs/ laptops	New-generation PCs/laptops
Capacity	Lower	Higher	Very high

Conclusion: DDR5 provides higher speed and lower voltage compared with DDR3 and DDR4.

2. RAM Module Installation

First, shut down the computer and disconnect the power supply. Locate the RAM slots on the motherboard and identify the RAM module.

Open the RAM slot clips and carefully remove the module. Align the notch on the RAM with the slot and press it down evenly until the clips lock into place.

After installation, reconnect the power and start the computer. Check the system information to confirm that the RAM is detected correctly.

Proof: Attach a clear photo of the RAM module and RAM slot.

3. HDD vs SSD vs NVMe

Storage | Main Difference | Speed | Example Use

HDD | Uses spinning magnetic disks | Slow | File storage, movies and backups

SSD | Uses flash memory, no moving parts | Fast | Windows and daily applications

NVMe SSD | Uses PCIe interface | Very fast | Gaming, video editing and large applications

Examples:

- HDD: Storing large collections of photos/videos.
- SSD: Fast Windows boot and everyday applications.
- NVMe: Gaming and video editing where fast loading is useful.

4. Storage Drive Installation

Before removing a storage drive, shut down the computer and disconnect the power. Locate the storage drive and identify its connector type, such as SATA or M.2.

Carefully remove the drive, take a photo of the connector, and reinstall it correctly. Reconnect the power and start the computer.

After restarting, check This PC or Disk Management in Windows to confirm that the storage drive is recognized.